# Input - Output Configuration

The flag is needed to synchronize the timing
rate between I/O devices and computer.



*The mux is for lsb only.